



DIGITAL SCALE PRECISA RECALIBRATION




**YOUR
COFFEE
EXPERIENCE**



1 Power on the scale




3 Put on the scale the weight 100g;
the display will show C1.




When power on in full digits 8888 press
and hold the TIMER button,
at the same time press the ON/OFF button
for 3 times quickly.

2



Remove 100 g and put the weight 500g;
the display will show C2.


4



5 Remove 500 g and put the weight 1500g;
the display will show C3.

After the following passages,
the display will show F1 1500g

6



7 Removing the weight the display
will show F1 0.0g

